

STAR Trigger TCD Crate Layouts

front:

VPD TCD (0x1f grp id=n/a)																				
PMD TCD (0x1d grp id=7)																				
FTPC TCD (0x1c grp id=0)																				
BTOW TCD (0x1b grp id=3)																				
CTB/ZDC TCD (0x1a grp id=n/a)																				
BSMD TCD (0x19 grp id=4)																				
SVT TCD (0x16 grp id=0)																				
TPC TCD (0x1e grp id=0)																				
ESMD TCD (0x10 grp id=6)																				
TOF TCD (0x15 grp id=2)																				
FPD TCD (0x14 grp id=1)																				
SSC TCD (0x13 grp id=0)																				
ETOW TCD (0x12 grp id=5)																				
BBC TCD (0x11 grp id=n/a)																				
GLink trans (busy out)																				
GLink recr (daq busy)																				
tcd.trg.bnL.local																				

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21
cable driver																				5V power and fan

1A2-2/3 Rack

12 mar 2007 j.engelage